



1. Replace the vacuum bag regularly

2. Check that the vacuum bag is properly attached

3. Empty bag-less models often

4. Clean the brush roll

- Clear the brush roll of any hair and debris and inspect by placing it on its end and spin. The brush should spin freely. If it doesn't spin; it may be time to replace.

5. Check the belt

- The general rule of thumb is belts should be replaced every 6 months to a year, depending on frequency of use. If you vacuum everyday, belts will need replaced every few months.

6. Check filters and hoses

- Cleaning your filter is very important. You can rinse plastic filters and shake out paper or fabric filters. Check hoses by looking into one end and/or sticking a hook inside to see if you can feel a clog.